
SDR-Kits Female Calibration Kit of Rosenberger parts for the DG8SAQ VNWA by Kurt Poulsen OZ7OU Revision 4 Oct 2014



On this sheet you will find the settings required in "Calibration Settings" and "Simple SOLT" for the Reflection (S11/S22) and Transmission (S21/S12)

- Please note that if you want to calibrate to the Reference plane of the VNWA Female TX SMA connector on the cabinet, then you must use a male Calibration Kit. Else look at the "How to..." below.


 When using testcables and measuring both S11 and S21, then the Thru adaptor is used, during S21 calibration, but removed during real measurements. To compensate for the changed transmission delay between the TX and RX port, you have to enter the delay for the Thru adaptor in the calibration settings. When doing so the reference planes for both reflection and transmission remain "in sync" at the chosen testcable's calibration plane.

- When the test cables have male SMA at the testing end, the Female Calibration Kit data is used, and likewise for female SMA the Male Calibration kit data is used.

- Do not use the Crosstalk Calibration for general use.
- Always set Delay Thru to 0 ps else transmission and reflection is not "in sync" any longer.

The Rosenberger Female-Female adaptor has a delay of 42.35ps.

The Rosenberger Male-Male adaptor has a delay of 78.81ps at VHF decreasing to 76.7ps at 1MHz



If using an empty Female Thru adaptor (no center conductor no PTFE insert) then the SMA male center conductor is used as the Open standard. Thus the delay used is very small being 2x -5.0ps= -10.0ps.

Revision 4 Updated: 26/12/2014

A few Hints:

The calibration Plane can be moved forward and backward by using Measure/Port Extensions. Port 1 used for the forward direction (S11 and S21), and Port 2 used for the reverse direction (S22/S12). During reverse direction the DUT is reversed. For a positive delay the Calibration Plane is moved away from the TX port and Vice Versa. If the TX level is changed the calibration is also changed slightly. READ ALSO THE HELP FILE

Velocity factor for calculation of calibration standard lengths Velocity Factor = 0.7 Compatibility seting to previous software versions. If unused set to zero! Note: This setting shifts transmission and reflect calibration planes against each other It acts as a port extension and will only be active if port extensions are enabled.

Delay Thru (formerly in Port Extensions)

Delay S21= 0.00ns